




AUTOCONER SPARES

Spares for High Speed Winding Machine



Schlafhorst Autoconer 238 Schlafhorsk Autoconer 338

Schlahfhors Autoconer Ac5 & X5 Schlafhorsk Murata Mach Coner

Star Volkmann TFO Savio Autoconer



SHREERAJ CORPORATION

Weaving & Processing Spares Suppliers



Gr. floor , Nikumbh Complex , opp. Tomato
Restaurent , Off C G Road, Ahmedabad 380006



+91 99137 99333, 079 4844 9933
sales@shreerajcorporation.com



Schlafhorst Autoconer Model 238



20203-45
WASHER



20235-44
FILTER SCREEN



40T GEAR & SHAFT
CONVEYOR TUBE ASSEMBLY



27050-04
MAGAZINE CARRIER



27050-09
MAGAZINE HALF




27050-13
MAGAZINE HALF



30107-02
CPL SWITCH HOUSING



30107-03
SWITCHING HOOD



30107-12
COVER



30120-12
PISTON



30120-901
CRADLE SHOCK ABSORBER



30380-15
DEFLECTION PLATE



30380-17
DEFLECTION PLATE



31601-03
GUIDE BAR (UPPER)



31601-03
GUIDE BAR (LOWER)



32501-31
SWIVEL BOLT



32501-33
PIVOTING SLEEVE



32501-42
CAM PIECE



32510-34
OPENER ARM



33005-34
TOOTHED SEGMENT



33001-14
PILOT MOTOR SHAFT



33001-14
PILOT MOTOR WORM



33001-14
PILOT MOTOR GEAR



33010-13
CAM (FU 2.1)



Schlafhorst Autoconer Model 238



33012-66
CAM FOLLOWER (FU2)



33015-13
SUCTION TUBE



33020-09
COMB STRIP (0.3 & 0.5)



33045-09
SCISSORS HOUSING



33045-14
SCISSORS SHAFT



33045-16
COVER



33045-19
SCISSOR BLADE
(CARBIDE TIPS & HSS)



33045-20
SCISSOR BLADE
(CARBIDE TIPS & HSS)



34101-03
CYLINDER



34101-07
FASTING PIECE



34101-08
GUIDE BUSH



34101-14
BEARING SHAFT



34101-17
BRAKE BUSH



34101-37
CPL BRAKE RING



34101-68
HOLDING RING (ALL SIZE)



34101-77
HOLDING RING (PU)



34201-10
BEARING (51107X)



34201-17
CPL ADOPTER (LH)



35101-21
LATCH



35101-81
STATIONARY SHEAR BLADE
(CARBIDE TIPS & HSS)



35101-84
PIVOTONG SHEAR BLADE
(CARBIDE TIPS & HSS)



35101-96
TOOTHED SEGMENT



35101-113
TOOTHED SEGMENT



35101-208
LEVER



Schlafhorst Autoconer Model 238




35101-211
CONTROL BOLT



35201-40
BOBBIN PEG



35301-12
IC MODULE (DRIVE)



35301-104
TRANSFER ROD



35301-133
GUIDE WIRE



37201-10
CONTROL LEVER



146 MODEL
SWIVEL LID



37701-20
SPACER RING



37701-20
LID BEARING



37701-67
SWIVEL LID



37701-75
CONTROL LEVER



40101-33
TENSION DISC



40101-55
TOOTHED WHEEL



40105-10
HOLLOW SHAFT



40105-19
TENSION DISC



40105-66
GUIDE PLATE



40160-05
ACTUATING LEVER



40160-44
STATIONARY SHEAR BLADE
(CARBIDE TIPS & HSS)



40160-50
PIVOTING SHEAR BLADE
(CARBIDE TIPS & HSS)



41001-03
SUPPORT ANGLE



41001-34
ACTUATING FORK



41001-41
DOUBLE LEVER



41501-102
CUTTING KNIFE



42001-15
DRIVE SHAFT



Schlafhorst Autoconer Model 238



42001-19
COUPLING GEAR



42001-37
TOOTHED LEVER



42001-47
GUIDE PLATE



42001-97
WAX SHAFT



42001-104
WAX CARRIER



42001-107
YARN TRAP



42001-902
CPL. WAXER SOCKET



42001-903
CPL. LIFTING PLUNGER



42030-09
TOOTHED WHEEL



42030-14
BEARING SHAFT



42501-46
NOZZLE (BIG)



42501-37
NOZZLE (SMALL)



42035-08
TOOTHED SEGMENT



56801-70
TOOTHED SEGMENT



56801-98
PINION



56801-170
BALL SOCKET



56801-202
AIR DUCT



56801-210
CPL. SCISSORS PLATE



56801-225
SCISSORS BLADE
(CARBIDE TIPS & HSS)



56801-230
SCISSORS BLADE
(CARBIDE TIPS & HSS)



56801-310
COVER (13 & 16 MM)



56801-357
DISTRIBUTOR



56801-433
COUPLING HALF



61001-09
NYLON GEAR 19T



Schlafhorst Autoconer Model 238



CONVEYOR GEAR



61001-26
SHAFT



61001-31
CPL. ROLLER



63020-03
LEVER WITH MAGNET



65101-04/05
SHAFT



65101-35
COVER



75203-04
BELT SHIFTER (BRACKET)



80591-17
BOBBIN CARRIER
(CADDY BASE)



80591-30
BOBBIN CARRIER
(18-21 & 20-30)



80591-30
BOBBIN CARRIER
(22-25 & 24-28)



81260
SUPPORTING DISC



81260-146
ROUND BRUSH



81260-451
SUPPORTING RING



81560-20
CENTERING



85035-44
SCISSOR BLADE
(CARBIDE TIPS & HSS)



85050-116
TOOTHED LOCK WASHER



85050-117
TOOTHED LOCK WASHER



85050-125
TOOTHED LOCK WASHER



85530-18
PINION SHAFT



85530-140
CAM



85530-152
CAM



99910-46
PULLER DEVICE



99910-65
STRIPPING POT



F 208897
CAM ROLLER BEARING



Schlafhorst Autoconer Model 338



20230-77
CPL. CYLINDER



20230-105
FILTER SCREEN



27070-02
CONE MAGAZINE



27251-62
BELT SHIFTER



27236-13
MOUNTING WHEEL



30101-27
MODULE



30105-06
COVER



30107-04
SLIDER (BLUE & GREY COLOUR)



30120/6
MAGNETIC COIL



30110-05
CLAMPING LEVER




30115-11
TOOTHED SEGMENT



30120-11
COVER



30120-14
UNIVERSAL JOINT



30120-22
SEAL RING



30125-05
CLAMPING LEVER



30125-07
STOP CAM



30125-22
STOP BRACKET



30125-31
CLAMPING LEVER



30125-35
STOP LEVER



30125-38
SHAFT



30130-06
COMPENSATING LEVER



30130-11
SPRING BRACKET



30130-28
SCALE



30301-04
MOTOR HOUSING



Schlafhorst Autoconer Model 338



30301-18
LOCKING LID



31320-09
LEVER



32510-22
OPENER ARM



32510-42
PACKAGE CRADLE



32510-45
CRADLE ARM BUSH (MODIFY)



32530-01
CPL. ADOPTER (RH)



32530-03
CYLINDER



32530-08
GUIDE BUSH




32530-14
BEARING SHAFT



32530-17
BRAKE BUSH




32530-18
FASTENING PIECE (MODIFY)



32530-20
BRAKE LINING (TEFLON)



32530-36
BRAKE RING (CNC)



32530-60
HOLDING RING (3'30)



32530-70
HOLDING RING (5'57 & 4'20)



32530-70
HOLDING RING (PU)



32535-10
CAP



32535-18
BEARING




33001-60
CPL. GEAR BOX ASSLY.
(MODIFY DESIGN)



33001-60
CPL. GEAR BOX
(MODIFY DESIGN)



33001-61
GEAR BOX COVER
(OLD DESIGN)



33001-62
TOOTHED WHEEL
(Z 80 X 12)




33001-64
TOOTHED WHEEL
(Z 86 X 12)



33001
TOOTHED WHEEL (STEEL)
(Z86 X 12 & Z80 X 12)



Schlafhorst Autoconer Model 338



33001-65
 GEAR BOX COVER PLATE
 (OLD DESIGN)



33001-68
 SHAFT



33001-69
 TOOTHED WHEEL (Z-22)



33001-88
 VALVE




33010-06
 CAM SHAFT



33010-8 & 11
 TOOTHED WHEEL WITH CAM



33010-09
 MAGNET HOLDER



33010-12
 CAM



33010-13
 SWITCH CAM



33010-15
 SPACER WASHER



33010-18
 CAM FOLLOWER



33010-35
 TOOTHED SEGMENT



33010-43
 TOOTHED SEGMENT



33020-04
 SUCTION TUBE




33020-06
 CLIP



33020-07
 CLAMPING PIECE



33045-15
 SUCTION CONNECTION



33045-05
 HOUSING



33045-08
 BOLT



33045-10
 LEVER




33020-09
 SUCTION NOZZLE



33045-16
 SNAP LOCK



33045-36
 PULL ROD



33045-38/39
 SENSOR BRACKET & GASKET



Schlafhorst Autoconer Model 338



33050-11
SUCTION PIPE SHUTTER



33050-22
PINION



33050-35
SUCTION DUCT



36001-62
TOOTHED WHEEL
(NEW DESIGN)



36001-62
TOOTHED WHEEL
FOR STEP MOTOR



36001-74
TENSION DISC



36001-74
WORM FOR TENSION DISC



36001-81
TOOTHED WHEEL (Z-31)
(NEW DESIGN)



36001-81
TOOTHED WHEEL (Z-31)
(OLD DESIGN)



36001-105
ACTUATING LEVER



36001-165
RUBBER SLEEVE



36010-122
INTERMEDIATE PIECE



36010-141
TENSION DISC



36010-153
BLOWER NOZZLE



36060-32
SWIVEL LEVER



36060-78
ACTUATING CAM



36010-18
YARN TRAP



36010-52
LEVER



36301-64
DRIVE SHAFT



36301-66
NOTCHED DISC



36301-68
LIFTER ARM



36301-70
LIFTING PLUNGER



DRUM PULLER



36301-144
WAX SHAFT



Schlafhorst Autoconer Model 338



36401-05
BRACKET



36405-55
SLUB CATCHER HOLDER



36801-56/57
CAM FOLLOWER



36801-92
EXHAUST CHANNEL



36801-97
PULL ROD



36801-109
PULL ROD




36801-116
LEVER



36801-125
LEAF SPRING



36801-155
WORM WHEEL



36801-460
PRISM (ALL SIZE)



37701-38
BEVEL GEAR



37701-43
DRIVE LEVER



37701-92
LID BEARING




37701-104
SWIVEL LID



37710-32 & 33
TOOTHED WHEEL
(Z-32/Z-48 & Z-14/Z56)



37710-131
SENSOR BRACKET



37740-23
TRANSFER ROD



37760-08
CONTROL LEVER



50190-09
CHAIN LINK



52030-01
CAM FOLLOWER



52030-35
UNIVERSAL JOINT



52030-140
LEAF SPRING




52140-06
DRIVE WHEEL




78010-49
FOOT (CADDY BASE)



Schlafhorst Autoconer AC5 & X5



30107/1-149008379
LAMP CAP



37720/162-149010980
SLIDE PANEL



37720/47-149000359
MALTESE CROSS



37720/192-149000833
LOCKING LEVER



37720/62-149001043
TOOTHED SEGMENT



37720/63 & 64
149001042-149001041
FEEDER ARM



37720/27-149000369
CHUTE LEVER




37720/70 - 149010310
STRAP



37720/160 -149000899
COUPLING ROD



37720/153-149000580
OPENER ARM



30107/5-149008381
CAP



37720/16-149004560
DRIVE SHAFT GEAR ONLY
TOP & BOTTOM



37756/7-149000933
COVER



37720/124-149011303
SLIDE CURVE LEVER



36802/36-149010646
LID LEVER



37720/120 & 109
149006239-149006238
CAM DISK



37720/41-149001044
FEEDER ARM



37720/20-149012385
CAM FOLLOWER



37720/137 & 138-149010236-149010234
CREEL ADAPTOR



30132/38
GEAR



37720/49-149004535
INDEXING PLATE



37720/37-149004551
DRIVE PINION



36301/1-149008440
COMPONENT CARRIER



37720/171-149004182
CENTERING DOOR BRACKET



Schlafhorst Autoconer AC5 & X5



149005382-30107/4
SEALING CAP



149005557-37720/108
CAM DISK



149003152-36320/21
WAX SHAFT



149001310-36320/24
THRUST WASHER



149009400-37720/130
EJECTOR



149003537-36301/6
AIR SWITCH



149002658-37720/134
HOUSING COVER



149004735-37720/179
CENTERING CHUTE



36320
WAXING DEVICE



14900563-37720/131
EJECTION PLATE



149001378-36020/20
BLOWER NOZZLE



149004517-37720/147
CAM FOLLOWER



32535/92
CLUTCH RING



149001540-30105/9
DIFFUSER



149001425-30105/2
PUSH BUTTON



149003452-30105/4
PUSH BUTTON



149001429-30105/6
INSERT



149003707-30105/1
HOUSING



149000556-37720/107
BEVAL GEAR




149000389-37720/72
STRAP



149002434-37720/148
COUPLING ROD



149005345-30105/7
DISPLAY




149002639-36802/82
COVER



TENSION DISC



Schlafhorst Autoconer (Electronics Spares)



16160-01(148)
INFORMATOR
TOUCH SCREEN



16161-01 (147)
INFORMATOR
KEYPAD



16161-01 (147)
INFORMATOR
DISPLAY (FRONT)



16161-02 (147)
INFORMATOR
DIAPLAY (BACK)



17550-160 (146)
INFORMATOR
KEYPAD



30105-01
CPL. OPERATION
SECTION



30105 901
CPL. INDICATOR UNIT



30107-13
CIRCUIT BOARD



30301-19
SENSOR
FOR DRUM SHAFT



31635-40
S6 SENSOR



31635-41
S7 & S8 COMBINED
SENSOR



32530-35
SENSOR



34101-35
S4 SENSOR



34101-35
S4 SENSOR (MODIFY)



34101-35
S4 SENSOR
(ROUND CABLE)



34101-37
PILE WHEEL
FOR BRAKE RING



36201-41
SENSOR-YARN TENSION
WITH PROTECTION COVER



42035-10
ELECTRO MAGNET (24V)



65230-70
INITIATOR (ALL TYPES)





32530/30
PILE WHEEL

Pls. Contact for Other Electronic Spares Other than Above Photographs, for Schlafhorst and Murata Winding Machine



PCB Repairing

We can Repair All-most all Electronic Spares & PCBs for
Schlafhorst and Murata Winding Machines
Pls. Contact for Further Details





Murata Mach Coner (Model 7-II, 7-V, 21-C)



003-41B-009
HANDLE STUD



003-41B-013
BUSH



003-41B-013
CRADLE BUSH



003-41B-034
LEVER



003-42A-011
NEEDLE BEARING



003-42A-019
BUNCH GUIDE



003-42A-032
BEARING CENTRE COMPLETE



003-42A-037
HOLDER




003-42A-038
BRAKE SHOE



003-422-001
SLEEVE



003-601C-003
YARN TRIP



003-601C-004
YARN TRAP HOLDER



008-45B-005
YARN GUIDE LEVER



008-45B-009
MECHANICAL VALVE



008-45B-022
CAM S2



008-45B-062X
GUIDE FOR S10 LEVER



008-45B-062X
LEVER-S10



008-45B-064
SHAFT



008-45B-067
S10 CAM SPLICING BLAST



008-45B-081
HOSE ADAPTER



008-45B-002X
HEAD PUSHING



008-50A-008A
RATCHET WHEEL



008-50A-028X
MAGAZINE BRACKET



008-52A-015
TRAP DOOR (LH)



Murata Mach Coner (Model 7-II, 7-V, 21-C)



008-52A-018
TRAP DOOR (RH)



008-220-008
ROLLER



008-310-022
PLATE



008-330-001
DRUM STAY SHAFT



008-330-007
DRUM BELT



008-330-025X
BRAKE LEVER



008-330-028X
BRAKE SHOE (OLD)



008-330-028X
BRAKE SHOE (NEW)



008-330-033X
DRUM SHAFT



008-330-036
DRUM COVER



008-331-006X
DRUM PULLEY COMPLETE



008-350-007X
SUCTION DUCT



008-350-010
COMB



008-360-002X
GRIPPER ARM COMPLETE




008-360-008
COVER CLAMP



008-360-034
YARN GUIDE



008-370-005
FIXED CUTTER



008-370-006
MOVABLE CUTTER



008-370-016X
SHUTTER CASE



008-380-003X
GEAR (RETIE PIPE SEGMENT)



008-380-013X
LEVER -A13 (MEMORY CAM)



008-380-021
REVERSING ROLL CAM



008-380-024
MEMORY CAM



008-380-026
DRUM START CAM



Murata Mach Coner (Model 7-II, 7-V, 21-C)



008-380-038X
GEAR (MOUTH SEGMENT)



008-390-003
MO-GEAR (DRIVE)



008-390-004X
CAM CLUTCH



008-410-058
BUNCH GUIDE



008-480-006
NOZZLE PIPE (8MM)



008-480-006
NOZZLE PIPE (ALL SIZE)



008-480-012
LEVER



008-480-013
LEVER



008-480-022
LEVER (STOPPER)



008-480-026X
LEVER-INTERMEDIATE



008-480-045
CLAMP SPACER



008-480-062
AIR GUIDE



008-480-081
CUTTER (FIXED)



008-480-082
CUTTER (MOVABLE)



008-480-089X
PLATE (FRONT)



008-480-094
YARN GUIDE FOR
NOZZLE SPINDLE



008-502-006X
HOUSING GEAR



008-502-013X
GEAR SEGMENT



008-530-013X
BOBBIN EJECTOR



008-552-002
PULL BUTTON
WITH SINGLE PIECE



008-533-004
WHEEL RATCHET



008-553-047 & 048
ARM FEELER



008-570-005
DRIVE GEAR (KO)



008-570-006X
CAM CLUTCH



Murata Mach Coner (Model 7-II, 7-V, 21-C)



008-570-013
REVERSABLE ROLL



008-601-006
YARN TRAP PACKING



008-602-016
TENSER DISK



008-602-017
TENSER DISK



008-603-007
CUTTER (MOVABLE)



008-603-008
CUTTER (FIXED)



008-603A-037
YARN GUIDE (TENSER)



008-604-004X
WAX PUSH LEVER



008-604-008
WAXING SHAFT



008-604-026
YARN GUIDE



008-604-029
WAXING BRACKET




008-604-044
GEAR SPUR



008-604-045
YARN GUIDE



008-E30-018
SENSOR



21A-200-034
BRUSH



21A-350-001
DRUM



21A-377-001
BLOCK



21A-380-014
COVER



21A-390-019
CYLINDER



21A-390-020
PISTON



21A-410-013 & 014
HANDLE WITH KNOB



21A-410-017
HANDLE STUD



21A-411-005
BUSH



21A-420-001
SLEEVE



Murata Mach Coner (Model 7-II, 7-V, 21-C)



21A-422-001
CPL. BEARING CENTER



21A-422-008
BEARING CENTER CAP



21A-422-009
BRAKE SHOE



21A-422-017
HOLDER BEARING CPL.



21A-422-100
CPL. BEARING CENTER



21A-426-002
BEARING HOUSING



21A-426-100
CPL. BEARING CENTER



21A-440-006
SHAFT



21A-440-006
CYLINDER



21A-480-041
LEVER ASSELY.



21A-520A-028
BODY




21A-520A-031
GUIDE CERAMIC



21A-540-003
GUIDE CERAMIC



21A-540-004
GUIDE CERAMIC



21A-540-017
GUIDE CERAMIC



21A-540-018
LEVER



21A-540-029
GUIDE CERAMIC



21A-540-030
GUIDE CERAMIC



21A-560-003
SHAFT WAX



21A-560-013
GUIDE CERAMIC



21A-608H-047
PIPE



21A-608H-048
BUSH



21A-627-044
WIRE



BUSH-DIFFERENT PART
NUMBER



Savio Auto Coner (Model: Espero, Espero-L, Orion)



1-48 01679-0 15320.0002.1-0
BRAKE SHOES AS-0020 5



1-49 01447-2 1420.0228.6
CONE HOLDER ADAPTOR



1-49 01447-2 1686.0168.2.0 &
161101.0174.0.0 GASKET



1-52 16200.3917.0.0
COMB STRIP



1-52 01444-8 16291.0044.0/0
FITTING AS-0181-18



1-52 01444-8 15426.0081.0.0
COVER CPL AS 0470



1-54 01503-4 16406.0110
DRAGGING UNIT



1-54 01503-4 16846.0113.0.0
& 16856.0377.0.0 COVER & SHOE



1-57 01600-3
16910.0929.0.0 SPRING



1-58 01653-0
16020.1030.0-0 3 LEVER




1-58 01653-0
16140.3448.0.0 PEG



1-117 AS-0421-15
& CUTTER



1-121 AS-0460
SUPPORT CPL GROUP



1-126 15201.0002.1.0
YARN TENSIONER



1-126 AS-0241 98
BUSH CPL GROUP



1-132 AS 0181-8
DISC



1-142 00613-1
16526.0079.0.0 GEAR



1-145 AS-0600-5
CAM



1-147 AS-0581 15
PULLEY



1-153 AV-0080 5
CAM



1-153 AV-0080-13
GEAR



17907-0749-1.0-00
CLUTCH



CHAMBERS



FRICTION ROLLER



Star Volkmann TFO



104-1 DUO-BELT
PULLEY CPL



105-3 COUPLING



106-1 S-Z SHAFT CPL



106-5 S-Z BEARING SMALL



106-6 S-Z BEARING
MEDIUM



111-2 CHANGER GEAR
BRACKET RH & LH



111-10 RATCHET GEAR



111-14 CHANGE
GEAR STUD



111-14 STUD



111-15 QUICK
LOCKING DEVICE



118-2 CAM CPL WITH ANTI
PATTERNING DEVICE 152MM



118-FREE WHEEL CPL



118-18
PAWL



120-1 TRAVERSE
SLIDE CPL



120-3 & 4 ROLL
RIGHT & LEFT



121-1 CHAIN TENSION
DEVICE CPL



301-1 SPINDLE
UPPER PART CPL



301-4 THREAD GUIDE
ONE WAY



301-4 THREAD GUIDE
DUAL WAY



301-4 THREAD GUIDE
DUAL WAY VTS 09



310-5 BRAKE LINNING



302-1 SPINDLE
LOWER PART



3202-3 BRAKE
SHOE BAKELITE



302-3 BRAKE
SHOE STEEL



Star Volkmann TFO



313-4, 5 SUPPORT
RH. MIDDLE, LH



314-5 SUPPORT



314-10 SUPPORT



315-1 PRE TAKE-UP
ROLLER CPL




315-1 PRE TAKE-UP
ROLLER CPL CERAMIC



316-1 INTERMEDIATE
SUPPORT



317-8 TRAVERSE THREAD
GUIDE WITH SUPPORT CPL



317-16 TRAVERSE
COUPLING



303-20 BALL CAGE
WITH INNER RACE



318-2 BALL BEARING
WITH SLEEVE



318-4 FRICTION DRUM
6"



318-4 FRICTION ROLLER
WITH APRON VTS 06S



319A-1 CONSOLE
ASSEMBLY CPL VTS 07



319A-2 REST FEEDER SPRING
FOR CONSOLE



319A-7 & 15
LAGER & KUFE



319A-18 DRUCK
FEEDER SPRING



320-1 CRADLE CPL
FOR VTS 065



320A-1 CRADLE CPL
FOR VTS 07



320-16 CENTERING DISC
(MULTI PURPOSE)



341-1 INSTANT LUBRIVIST
ASSEMBLY



342-15 REFILLING PISTON
WITH SCREW CONNECTION



SPRING



SUPPORT CPL WITH
WAX DISC



SUPPORT CPL WITH
WAX DISC



Volkmann TFO




174-1 SPINDLE UPPER
 PART CPL




174-09 BRAKE SHOE



180-24 VALVE VOLCOJET



184-01 OILING
 DEVICE CPL



188-01 YARN STOP
 MOTION CPL



209-06 VARIETER
 ASSEMBLY CPL



209-09 INTERMEDIATE
 PIECE



209-17 PISTON
 ASSY CPL



246-05 ADJUSTABLE BELT
 GUIDE ROLLER



246-17 BELT GUIDE
 ROLLER



253-32 PRE TAKE-UP
 ROLLER



254-01 COUPLE CPL,



254-46 NOZZLE



256-15 CENTERING
 DISC MULTIPURPOSE



260-21 DEFLECTION ROLL



266-31 & 266-32
 LEVER & HOUSING



359-09 PACKAGE
 SUPPORT CPL



359-09 PACKAGE
 SUPPORT CPL



359-12 BALL CARE
 WITH INNER RACE



360-16 TENSION
 CAPSUEL



360-01 M.T.
 DEVICE CPL



FREE WHEEL COUPLING



SLEEVE &
 BRAKE SHOE



V CLAMP



Prerna Leewha TFO



164-1415 COUPLING
CPL



164-1431 S-Z GEAR SHAFT
CPL WITH BEARINGS




164-1506 TRAVERSE CAM



164-1520 CAM
ROLLER PIN



164-4104 WEIGHT WASHER



164-4106 FLYER



164-4117 & 4118 UPPER &
LOWER CAPSULE WITH SPRING



164-4201 SUPPLY
PACKAGE CPL ASSY.



164-4201 SUPPLY
PACKAGE




164-4201A SPINDLE
CPL HZ 33-35



164-4207 TENSOR
SOCKET CPL



164-4603 TENSION
ROLLER BRACKET



164-4604 TENSION
ROLLER CPL



164-4701 BRAKE ARM



164-4702 BRAKE SHOE
WITH LINER




164-4708 BRAKE
ROLLER CPL



164-4708 BRAKE
ROLLER




164-4804 UNDER ROLLER
CPL ASSY. WITH BRG



164-50355A DRUM
WITH FRICTION RING



164-4708 BRAKE
ROLLER CPL



164-5113, 5116 CONE
HOLDER BRG TYPE



164-5502 C.T. HOUSING
CPL ASSY



164-5310 BEARING CAP



164-5407 TRAVERSE
YARN GUIDE




Prerna Leewha TFO



164-6128 O. F. ROLLER CPL
WITH ROLLER TYPE DISC



164-6208 GUIDE
ROLLER CPL




164-6310 BALLOON
GUIDE BAR



164-6404 DROPPER
BRACKET



164-6408 STOP
MOTION SENSOR




164-6417B DROPPER CPL



164-7205, 7209 WORM
GEAR & WORM



164-7228 CONNECTING
ROD ASSY.



164-8115 TAILING
ROLLER



164-8310 WAXING
ROLLER CPL



560-2211 DRIVING
SHAFT



560-1813 TENSION
PULLEY



560-1818 TENSION
PULLEY SHAFT



560-4705 BRAKE
CONNECTOR CPL ASSY



560-4711 BRAKE
PADDLE BUSHING



560-4712 BRAKE
PADDLE STOPPER



560-5103 CRADLE
BRACKET



560-5103 CRADLE
BRACKET



560-5404 TRAVERSE
GUIDE HOLDER CPL



560-6201 GUIDE
ROLLER BKT CPL




164-6306 BALLOON
GUIDE BAR HOLDER




560-6305 BALLOON
GUIDE BAR HOLDER



560-6407 DROPPER
BRACKET



560-6408 DROPPER



SHREERAJ CORPORATION

Weaving & Processing Spares Suppliers



Gr. floor , Nikumbh Complex , opp. Tomato
Restaurent , Off C G Road, Ahmedabad 380006



+91 99137 99333, 079 4844 9933
sales@shreerajcorporation.com

